

Quick Reference Guide

March 2017
Version 2017.0

Chapter 5 – Framing Interior Walls

Preparation	<ol style="list-style-type: none">1. Start by building the longer walls that intersect the exterior walls.2. Remove the temporary nails connecting the upper and bottom plates and separate on the deck. Be sure the words “Upper” and “Bottom” remain in the same orientation.3. If not presorted, select studs for framing walls and sight along the edge to determine the crown. Mark with an arrow pointing to the high side.
Building the Walls	<ol style="list-style-type: none">4. Place the studs, crown up, and door components in position between the plates per the marking on the upper and bottom plates. (Do not use a stud if severely crowned.)5. Make sure the studs are flush with the edges of the plates and that the end studs are flush with the ends of the plates. Nail with <u>two</u> 16d or 3¼” Paslode nails.

Quality Points

Chapter 5 – Framing Interior Walls